

PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

- * All pipework must be thoroughly flushed prior to installation.

Installation

- 1) Check that threaded nipple (1) is the correct length, as shown
Cut to length if required ensuring end face is square.
- 2) Apply thread tape to the thread. Screw the bath outlet (2)
onto the threaded nipple (1) and position as required.
DO NOT OVERTIGHTEN .

IMPORTANT

Pressure & Temperature Requirements.

- Hot and cold water inlet pressures should be equal.
- Static Inlet pressure range : 150 -1000 kPa
New Regulation :-500 kPa maximum static pressure
at any outlet within a building.
(Ref. AS/NZS 3500.1-2003, Clause 3.3.4)
- Maximum hot water temperature : 80°C.

