

CLARK[®]

R85

PPL10BU Polar Single Bowl Undermount INSTALLATION INSTRUCTION FOR UNDERMOUNT SINK

1. Inspect sink for damage and dimensional compatibility. Do not attempt to install a damaged sink.
2. Undermount sinks are designed for use with solid surface benchtops, examples as follows;
 - Natural Stone eg. Marble, Quartz etc
 - Engineered stone eg. CaesarStone, Silestone etc
 - Acrylic solid surfaces eg. Corian, Freestyle, Staron etcIt is not recommended that undermount sinks be fitted to laminate benchtops.
Contact your benchtop supplier to establish the type of material used. Your supplier should recommend a suitable adhesive and sealant for the specified material.
3. Using the cut-out template mark the exact location of the required cut-out in the benchtop.
Ensure that the tap location is suitable. Ensure that the supplied cut-out gives the desired fit.
4. Using the appropriate tools and safety equipment cut the benchtop as marked out.
5. Mask the sink and the cut-out to avoid sealant/epoxy overspill onto finished surfaces.
6. Apply the recommended sealant at the edge of the join between sink and benchtop.
7. Apply the recommended adhesive as directed by adhesive supplier.
8. Position the sink in the desired final location and clamp to the benchtop.
9. Promptly remove excess sealant from benchtop and sink using a recommended clean up solvent suitable for your benchtop material and stainless steel.
10. When the installation has cured for the recommended period check that the seal is watertight and the attachment is secure.

GWA Bathrooms & Kitchens bears no responsibility for faulty installation and the effects thereof.

425 BENCH CUTOUT

372 BENCH CUTOUT

CUTOUT TEMPLATE DIMENSIONS
372mm x 425mm
Corner Radius: 85mm