


# CLARK

## 40MM POP-UP BATH WASTE WITH OVERFLOW CL60032.C

### INSTALLATION INSTRUCTIONS:

NOTE: READ ENTIRE INSTRUCTIONS PRIOR TO COMMENCING INSTALLATION

1. Maximum distance between Pop-Up Base and Overflow Elbow is 1200mm.
2. Check the suitability of Overflow Inlet (A) in bath position before drilling hole.
3. Carefully drill 48mm hole in position for the Overflow Inlet (B) in desired position if bath is not predrilled.
4. Measure and cut sufficient Flexible Pipe (E) required to connect the Overflow Elbow (A) to the Pop-Up Base (C).
5. Solvent weld Flexible Pipe (F) onto the Overflow Inlet and the Pop-Up Base, ensuring the pipe will not be twisted upon installation (use Type N PVC Solvent Cement).
6. Locate rubber seal onto Pop-Up Base and install Pop-Up Assembly (D) into bath outlet using the correct length screw. Do NOT use silicone.
7. Locate rubber seal onto Overflow Elbow and install with correct length screw. Do NOT use silicone.
8. Do NOT over tighten screws, use only hand tools. Do NOT use an electric screw driver as that may over tighten screws and cause the kit to deform.
9. Test as per AS 3500 before enclosing bath.



### Included in this kit:

- 2 - 25mm SS Screws
- 2 - 40mm SS Screws
- 1 - Overflow Elbow & Seal (B)
- 1 - Overflow Inlet (Chrome) (A)
- 1 - Pop-Up Base & Seal (C)
- 1 - Pop-Up Assembly (Chrome) (D)
- 1 - 1200mm Flexible Pipe (E)

WARRANTY EXTENDS TO REPLACEMENT VALUE ONLY,  
PROVIDED INSTALLATION IS TO MANUFACTURES INSTRUCTIONS.

FOR TECHNICAL INFORMATION PLEASE CONTACT CLARK ON 13 14 16