

PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

- * All pipework must be thoroughly flushed prior to installation.

Installation (Fig.1)

- 1) Check that threaded nipple (2) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread tape to the thread.
- 2) Select the desired cover plate (1) (round or square shape) and place over the threaded nipple (2), with the **Caroma** marking aligned horizontally at the bottom. Screw the spigot (3) onto the threaded nipple (2) using a 10mm allen key (4+) (not supplied) until the cover plate (1) is held securely against the wall/tile face. DO NOT OVERTIGHTEN. Apply suitable lubricant to 'O'Rings (5).
- 3) Fit wall outlet (6) onto the spigot (3), then carefully push it firmly against the cover plate while tightening grub screws (7) using the 2.5mm allen key (8) provided. Take care that the aerator (9) is pointing vertically downwards before tightening screws (7).
- 4) Turn on Hot and Cold water supplies and check operation.

IMPORTANT	
<u>Pressure & Temperature Requirements.</u>	
•	Hot and cold water inlet pressures should be equal.
•	Static Inlet pressure range : 150 -1000 kPa New Regulation:- 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1)
•	Maximum hot water temperature : 80°C.

+ Not supplied.




Fig. 1