

## PLUMBERS INSTALLATION INSTRUCTIONS

### Important Information

- \* All pipework must be thoroughly flushed prior to installation.
- \* Turn off hot and cold water supplies before installation.

### Installation

- 1) Check that threaded nipple (1) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread tape to the thread.
- 2) Ensure the 'O'Ring (2) is fitted to the groove in the cover plate (3), as shown. Slide the cover plate (3), with 'O'Ring (4) in position as shown, onto the bath outlet (5). Screw the inlet of the bath outlet (5) onto the threaded nipple (1) until its base is adjacent to the wall surface and the aerator insert is pointing down as shown, taking care not to damage the decorative finish. DO NOT OVERTIGHTEN.
- 3) Slide the cover plate (3) along the bath outlet (5) until the 'O'Ring (2) has contacted the wall surface.

IMPORTANT	
<u>Pressure &amp; Temperature Requirements.</u>	
<ul style="list-style-type: none"> <li>• Hot and cold water inlet pressures should be equal.</li> <li>• Static inlet pressure range : 150 -1000 kPa New Regulation :-500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1)</li> <li>• Maximum hot water temperature : 80°C.</li> </ul>	
<u>Installation Requirements.</u>	
<ul style="list-style-type: none"> <li>• The installing plumber is responsible for waterproofing all penetrations for Taps in Shower areas at installation by a proprietary flange system or a sealant. (Ref AS3740)</li> </ul>	




Fig. 1